

Citect for Windows
Driver Specification Extract
Trio Driver

Author: Philip Wong
Date: 16/6/95

Modified: David Rossini
Date: 17/02/98

Contents

1. TARGET DEVICE	4
1.1 INTRODUCTION	4
1.2 DEVICE MANUFACTURER	4
1.3 DEVICE DEFINITION	4
1.4 COMMUNICATIONS METHOD	4
1.4.1 Physical Layer (Layer 1)	4
1.4.2 Data Link Layer (Layer 2)	4
1.4.3 Radio Link Layer (Layer 3)	5
1.4.4 Frame Handling For Transmitting Data	7
1.4.5 Frame Handling For Receiving data	7
1.5 COMMUNICATIONS/HARDWARE CONFIGURATION	8
1.5.1 Wiring Diagrams	8
1.5.2 I/O Device Settings	8
1.5.3 Software Setup	8
1.6 SPECIAL REQUIREMENTS	9
1.7 MAXIMUM REQUEST LENGTH	9
3. USER INTERFACE	10
3.1 INTRODUCTION	10
3.2 DRIVER NAME	10
3.3 BOARDS FORM	10
3.3.1 Real Board	10
3.3.2 TRIO Board	10
3.4 PORTS FORM	11
3.4.1 Real Port	11
3.4.1.1 Port Name	11
3.4.1.2 Port Number	11
3.4.1.3 Board Name	11
3.4.1.4 Baud Rate	11
3.4.1.5 Data Bits	11
3.4.1.6 Stop Bits	11
3.4.1.7 Parity	11
3.4.1.8 Special Opt	11
3.4.2 TRIO Port	12
3.4.2.1 Port Name	12
3.4.2.2 Port Number	12
3.4.2.3 Board Name	12
3.4.2.4 Baud Rate	12
3.4.2.5 Data Bits	12
3.4.2.6 Stop Bits	12
3.4.2.7 Parity	12
3.4.2.8 Special Opt	12
3.5 I/O DEVICE FORM	12
3.5.1 Name	12
3.5.2 Number	12
3.5.3 Address	12
3.5.4 Protocol	13
3.5.5 Port Name	13
3.6 PULLDOWN LISTS HELP	14
3.7 PARAMETERS AND INI OPTIONS	14
3.7.1 Standard Parameters	14
3.7.2 Driver Specific Parameters	14
3.8 HINTS AND TIPS	14

4. REFERENCES.....15

4.1 REFERENCES.....15

1. Target Device

1.1 Introduction

This section defines the types of I/O Devices that are targeted by this driver.

1.2 Device Manufacturer

TRIO Communications 2000 Pty Ltd
41 Aster Ave Carrum Downs Vic 3201
Telephone: 61 3 9775 0505, Fax: 61 3 9775 0606

1.3 Device Definition

TC-900DR 900MHz Full Duplex Transceiver (Radio Modem)

1.4 Communications Method

ISO-OSI Layer	Name	Implementation
5-7	Application	Citect
4	Serial Driver	Citect Serial Protocols
3	Radio Link	TRIO Driver
2	Data Link	COMX
1	Physical	RS232

1.4.1 Physical Layer (Layer 1)

RS232

1.4.2 Data Link Layer (Layer 2)


COMX driver.

1.4.3 Radio Link Layer (Layer 3)

Point to Point modem connection



One to Many modem connection



"Repeater" modem connection

3

To understand the functionality required of this driver, it is helpful to first understand the functionality of the radio modems that the driver utilises.

The modems carry data in frames (packets), and are required to route these frames between points - the routing may be in a simple one-to-one relationship, a one-to-many relationship or a complex network.

As there could be many radio modems sharing the same frequency, all modems would receive all messages transmitted, and hence an addressing mechanism is required to ensure the routing integrity of the communication streams. This is achieved by marking the first byte of each frame as a Stream Identifier (SID) code.

1.4.3.1 Radio Modem Functionality

A modem has two ports and a diagnostics utility, each of these have parameters to store two SID code values. A modem port can be set to operate in one of two modes.

1.4.3.2 User Mode

When the modem port is routing messages on a simple point-to-point basis, it would be set to operate in the "USER" mode. In this mode, the port will receive frames matching its first SID code parameter (the Rx SID code). The SID code byte will be removed from the frame, and the message will then be passed on to its attached device (such as a PLC). Messages from the device will be broken into one or more frames for transmission, with the ports second SID code parameter (The Tx SID code) inserted at the start of each frame, prior to transmission. The modem port on the opposite end would also be set in the "USER" mode, with the Tx SID code parameter of one modem matching the Rx SID code parameter of the other, and vice-versa.

1.4.3.3 Trunk Mode

When the modem port is routing messages on a "repeater" basis to other selected modems, it would be set to operate in the "TRUNK" mode. In this mode, the port will receive frames which have a SID code that lies within the ports first SID code parameter (the Low SID code) and the ports second SID code parameter (the High SID code) inclusive. The SID code will not be removed from the frame, and hence the message will be passed on un-altered to its attached device (in this example, another radio modem acting as the "repeater"). Messages from the device are expected to be in a format ready for transmission (including the SID code), so no processing is required for transmission. In order to maintain integrity of messages with SID codes attached, a defined message framing sequence, such as SLIP (Serial Line Interface Protocol) encapsulation, is recommended. SLIP is a data transport protocol used in serial interface applications, the Diagnostics Controller Interface Manual listed in Section 4.1 describes the SLIP protocol.

1.4.3.4 Diagnostic Utility

A modems diagnostic utility will receive frames that match the modems Rx SID code for the diagnostic port. When a match is found, the diagnostic utility then compares the serial number of the modem against the serial number of the received diagnostic message. If the serial numbers match, then the diagnostic utility will reply, with the SID code of the reply frames set to the diagnostic utilities Tx SID code.

The Radio Link Layer sits between CITECT's low level serial driver (COMX) and the Citect serial protocol drivers. It allows the protocol driver to select which radio in the field it wants to talk to. The protocol driver does not have to be recoded in order to use this layer, they need only be re-linked.

The modem on the CITECT end must be in SLIP mode, live Frame mode disabled, using TRUNK mode (with the Low and High SID code parameters set to their outer limits). If there are multiple slave modems, or if the protocol being used is full duplex, the PTT (Press To Talk) should be permanently activated with RTS; the Diagnostics Controller Interface Manual, listed in Section 4.1, describes these matters in further detail.

The routing functionality of this modem is effectively made obsolete by this driver. As discussed above, the modem will relay, in TRUNK mode, all frames that it receives from either direction.

This driver allows the user to configure “virtual” ports for use by protocol drivers, with each “virtual” port providing the equivalent routing functionality of a radio modem. The user configures two SID code parameters per “virtual” port, the Rx and Tx SID codes, in the ports form..

This driver will send all communications from the “virtual” ports, to one physical comms port. This port is attached to the local radio modem, which then transmits the frames, to be received by the appropriate remote radio modem. All frames received by the local radio modem, from the remote radio modems, are in turn received by this driver through the physical port. The driver will then route the communications to the appropriate “virtual” port.

The modem on the PLC end should be configured according to the Trio Interface Bulletins. A bulletin defining User Port Setup details is available for most PLC and RTU brands.

1.4.4 Frame Handling For Transmitting Data.


Each buffer (message) to be transmitted can either be transmitted as one frame, or split into smaller frames (of a nominal size of 16 bytes), with each individual frame encapsulated in a SLIP envelope. The first byte inside the SLIP envelope is assigned the value of the Tx SID code parameter for that “virtual” port. Each frame is then sent to the radio modem via the physical port. Smaller frames are used to reduce the transmit delay, as the radio will only transmit when it receives an entire SLIP frame, however some protocols will not tolerate this message distortion and require the “virtual” port to enforce one frame per message. (See Trio interface notes for further information on message framing).

1.4.5 Frame Handling For Receiving data.

When a frame is received with a SID code that matches the Rx SID code parameter of a “virtual” port, the SLIP frame and SID code will be removed from the frame, and the data passed to that “virtual” port.

1.5 Communications/Hardware Configuration

1.5.1 Wiring Diagrams



1.5.2 I/O Device Settings

N/A

1.5.3 Software Setup

As discussed in section 1.4.3, the radio modems must be configured to match the actual network application. The configuration of the remote radio modems should be configured on an application basis as advised by Trio Interface Bulletins. A typical configuration for the local (base) radio modem follows.

1.5.3.4 Typical TC-900DR configuration for local radio modem

User Port A Parameters	
Async Baud Rate	9600 bps
Data Bits	8
Parity	None
Stop Bits	1
Flow Control	
H/W Handshaking	Yes
Packet Assembler/Disassembler (PAD) Setup	
SLIP mode	Yes
Live Frame mode	No
CTS Dependency	

CTS Inactive if RTS Inactive	Yes
Port B	
Enable Port B	No
Radio Parameters	
Tx Power	
Rx Carrier Min RSSI Level	-105 dBm
PTT Time-Out	
PTT Time-Out	Off
Min Tx Power	
Min Tx Alarm Level	100 mW
Drift Offset	
Drift Offset	0 (default)
System Parameters	
Lead In Delay	
Lead In Delay	60 mS
SID codes	
Enable SID codes	Yes
Port A	
Mux/Demux or Stream Routing	Stream Routing (M/D = USER mode, S/R = TRUNK mode)
SID A1 Code (Low SID code)	0
SID A2 Code (High SID code)	255
Diagnostics	
SID D1 Code (Low SID code)	0 (Depends on network configuration, refer to Section 3.8)
SID D2 Code (High SID code)	0 (Depends on network configuration, refer to Section 3.8)
PTT Activation	
Activate PTT with RTS signal	Yes
System Functions	
Collision Avoidance	Yes
Master or Remote	Master
Supervisory Functions	
Tx Channel Rate	1
Rx Channel Rate	0
Min RSSI Collision Avoidance Mode	
Min RSSI Collision Avoidance Mode	No
MODEM OPTIONS & REPEATER SETTINGS	
Port A – Enable/Disable Repeater	Disable

1.6 Special Requirements

Configuration of the radio modem parameters will require the use of a TC-DFM91P programmer.

1.7 Maximum Request Length

N/A

3. User Interface

3.1 Introduction

This section defines how the user will see the driver. This relates directly to how the Citect forms need to be filled out and any special INI options.

3.2 Driver Name

TRIO

3.3 Boards Form

Boards forms must be completed for both a real board and a TRIO board.

3.3.1 Real Board

The real board provides the physical data path for CITECT to communicate with a TRIO radio modem.
(*The settings below are for using the computers COM port*).

3.3.1.1 Board Name

User supplied unique name for board.

3.3.1.2 Board Type

COMX

3.3.1.3 Address

0

3.3.1.4 IO Port

NA

3.3.1.5 Interrupt

NA

3.3.1.6 Special Opt

N/A

3.3.2 TRIO Board

The TRIO board acts conceptually as a physical board, and provides the framework on which TRIO “virtual” ports are implemented. All data to/from the TRIO board has a physical path to the radio modem through the real port specified in the Special Options field.
TRIO boards must be defined after all real serial boards.
Up to 8 TRIO boards may be defined.

3.3.2.1 Board Name

User supplied unique name for board.

3.3.2.2 Board Type

TRIO

3.3.2.3 Address

0

3.3.2.4 IO Port

NA

3.3.2.5 Interrupt

NA

3.3.2.6 Special Opt

PortName of real serial port (attached to radio modem).

3.4 Ports Form

Ports forms must be completed for a real port and also a TRIO “virtual” port for each unique Rx SID code in the radio modem network.

3.4.1 Real Port

The port used to physically connect to a radio modem.

3.4.1.1 Port Name

User supplied unique name for real port.

3.4.1.2 Port Number

Port number for real port
(COM port number if using computers COM port)

3.4.1.3 Board Name

Name of real board.

3.4.1.4 Baud Rate

9600

3.4.1.5 Data Bits

8

3.4.1.6 Stop Bits

1

3.4.1.7 Parity

none

3.4.1.8 Special Opt

none

3.4.2 TRIO Port

A “virtual” port is to be configured for each protocol driver requiring communication over the radio modem. This includes the TRIO diagnostics driver.
Up to 100 “virtual” ports may be defined for the system.

3.4.2.1 Port Name

User supplied unique name for “virtual” TRIO port.

3.4.2.2 Port Number

Tx SID code (0 to 255)

3.4.2.3 Board Name

A TRIO board defined in Boards form.

3.4.2.4 Baud Rate

NA

3.4.2.5 Data Bits

NA

3.4.2.6 Stop Bits

NA

3.4.2.7 Parity

NA

3.4.2.8 Special Opt

The first five characters should be of the format “*Unnn” .

“nnn” is the Rx SID code parameter (0 to 255)

If using a protocol that doesn’t support its messages being fragmented into separate frames, such as modbus, include the “*M” flag as the seventh and eight characters. This will force the frame size to be that of the protocols message. Note that most protocols will NOT require this flag.

Any special options required for the protocol driver should be included after these flags.

3.5 I/O Device Form

3.5.1 Name

User supplied, unique for I/O device

3.5.2 Number

Network wide I/O device number

3.5.3 Address

Depends on protocol

3.5.4 Protocol

Protocol name

3.5.5 Port Name

Refer to "Port Name" in TRIO Ports form

3.6 Pulldown lists Help

The following entries should be included in the Citect HELP.DBF spec file.

TYPE	DATA	FILTER
BOARD	TRIO	

3.7 Parameters and INI options

3.7.1 Standard Parameters

N/A

3.7.2 Driver Specific Parameters

[TRIO]

FrameSize = 16 bytes. (Maximum frame size is 256 bytes.)

If the “*M” flag has not been set in the Special Opt field of a port, then messages will be broken into frames of size FrameSize prior to transmission.

3.8 Hints and Tips

The radio modem network should be set up such that all modems with a particular diagnostic Rx SID code also share a particular diagnosticTx SID code. For instance, a network may be constructed with SID codes 10 and 110 reserved for use as diagnostic Rx and T SID codes for a particular group of modems in the network. This grouping is required as the TRIO diagnostics driver will require a “virtual” port configured for each diagnostic group, and hence will require all valid diagnostic replies for a particular Rx SID code be transmitted to a corresponding Tx SID code.

4. References

4.1 References

TC-900DR 900Mhz Full Duplex Data Transceiver

User Manual. Issue 5

Programming Operators Guide. Issue 2.A : October 1994

Diagnostics Controller User Manual. Issue 3: September 1994

Application Note AN-D13 "External Stream Router Applications for the TC-900DR": March 1997